

Flat Pack Visor Kit



Description

Your flat pack visor kit will include the following items per visor:

- One size adjustable Polycarbonate film strap.
- One Polycarbonate film visor profile.
- Two sets of snap rivets to fix the visor to the strap.



Assembly Instructions

Remove the protective laminate from both sides of the head strap and adjust this to fit your head by slotting the attachment end into the necessary slot.

Peel the protective laminate from top corners of the visor profile on both sides to reveal the pre-cut holes.

Insert the male element of the snap rivets through the hole of both the visor and strap, then clip on the female element to secure the strap and visor together.

Your assembled visor should look as below:



The information provided herein was believed to be accurate at the time of preparation or prepared from sources believed to be reliable, but it is the responsibility of the user to investigate and understand other pertinent sources of information, to comply with all laws and procedures applicable to the use of the product and to determine the suitability of the product for its intended use.

